


WinCE 7.0 Integrated Mainboard

This board is the new revision that will be replacing the old I/O Board (Part Number: 7650000111). It no longer requires the smaller raised Mainboard (Part Number: 7650000167), as everything is integrated into one control board.




Software Update Process

It utilizes a different version of software that will be specific to these new boards, which is available on the NextATM website. When loading your storage device (SD Card/USB Drive) with software, you are no longer limited to using devices that are 4GB or less, as with the WinCE 6.0 and 5.0 boards. FAT and FAT32 are still the supported formatting file system types.

Once you've downloaded the software files to your computer, follow the instructions below in order to load them to your machine.

Bootloader (SD Card)


1. Unzip the .zip file and copy the two '.NB0' files and the 'Update7' folder to your SD Card (capacity size doesn't matter). Before loading files to your SD Card it is recommended that you format it beforehand.



2. Insert the loaded SD card into the SD card slot on the mainboard behind your screen (see pic above).
3. Press and hold the 'Boot menu' button (see pic above).
4. Press and release the 'Reset' button (see pic above).
5. The machine will reboot and load the 'Diagnostic Mode'.
6. Select the 'SD CARD' option.
7. Select 'Format & Upgrade' to reset the ATM application to Factory Defaults.
8. Once files finish downloading, select 'Reboot' on the screen.
9. ATM will boot up to a secondary Software Update screen, allow it to load these addition files automatically and reboot on its own.
10. Finally, you'll come to an 'FFFFFF - NVRAM Broken' Error Code. Do not attempt to log in yet.
11. Open your Vault Door.
12. Enter the following code on your keypad: CLEAR + LEFT ARROW + RIGHT ARROW + CLEAR + CLEAR + CANCEL
13. If you do it properly, the screen will ask you if you wish to reset the master password. Select 'yes' and the machine will reboot one last time.
14. Upon this final boot your machine will be back at default settings and you can remove the SD Card and log in with '555555' as your Master Password and begin re-programming your machine.

AP Software Update (USB Drive or SD Card)

1. Unzip the .zip file and copy the 'Update7' folder to your USB Drive/SD Card (capacity size doesn't matter). Before loading files to your storage device it is recommended that you format it beforehand.



2. Insert the loaded storage device into the mainboard behind your screen (see pic above).
3. Log into the Operator Function menu.
4. Navigate to SYSTEM SETUP > SYSTEM CONTROL > SOFTWARE UPDATE > USB SOFTWARE UPDATE and select 'yes'.
5. The ATM will then reboot and begin the update process. Once it's finished it will reboot one last time and return into service.